



Development environments



- Linux-based systems for higher flexibility and better interoperability
 - most of software tools are targeted for Unix
 - most of gateways devices are Linuxbased (Meshlium, Beagle, Rasperry,...)
- When possible, avoid Java development and priviledge C, C++ and scripts (shell, python)



Standard IDE & software tools

- Libelium WaspMote
 - Libelium IDE (Arduino-based) & API development environment
- AdvanticSys TelosB
 - TinyOS 2.1.2 development environment
- Audio
 - Codec2 software (<u>www.codec2.org</u>): c2enc, c2dec
 - Speex software (<u>www.speex.org</u>): speexenc, speexdec
 - sox and play package (Linux)
- Serial & frame analysis
 - minicom, cutecom
 - wireshark



Customized speex audio tools

- Simple « pure » speex audio decoder without any header
 - Modified version of speex's sampledec.c
 - speex_sampledec_wframing : expects framing bytes
 - speex sampledec nframing : no framing bytes
- To get a « pure » speex audio encoded file without any header
 - Modified version of speexdec.c (yes speexdec.c and not speexenc.c) compatible with speex's sampledec.c



Development of dedicated tools

- Serial tools to read host computer serial port
 - XBeeReceive (C language)
 - SerialToStdout (python script)
 - 115200 baud version
 - 38400 baud version
- Communication tool to send control command packets
 - XBeeSendCmd (C language)
- Communication tool to send binary files
 - XBeeSendFile (C language)





XBeeReceive

- XBeeReceive
 - Main target is 802.15.4 XBee-based gateway
 - Translates XBee API frame
 - Reads from the serial port: /dev/ttyusB0, /dev/ttys0, ...
 - Reconstructs file in binary mode (handles packet losses)
 - Assumes each packet with 4 bytes header: 2 bytes for file size & 2 bytes for offset
 - Can write to Unix stdout & can act as a transparent serial replacement
 - Can act in a data stream fashion: no header for packets

```
./XBeeReceive -baud b -p dev -B -ap0 -v val -stdout -stream file name
USAGE:
          -baud, set baud rate, default is 38400
USAGE:
          -p /dev/ttyUSB1
USAGE:
USAGE:
          -B indicates binary mode. Assumes 4-bytes header for each pkt (that will be removed)
USAGE:
          -framing expect for framing bytes 0xFF0x55 for binary data
          -ap0, indicates an XBee in AP mode 0 (transparent mode) so do not decode frame structure
USAGE:
          -v 77, use 0x77 to fill in missing value in binary mode
USAGE:
          -stdout, write to stdout for pipe mode in binary mode
USAGE:
USAGE:
          -stream, assumes no header & write to stdout for pipe mode in binary mode
USAGE:
          file name, name for saving binary file
```



SerialToStdout.py



- Simple python script to read serial port when no translation is needed
- Change baud rate and port as needed

```
import serial
import sys

ser = serial.Serial('/dev/ttyUSBO', 38400, timeout=0)

# flush everything that may have been received on the port to make sure
# that we start with a clean serial input
ser.flushInput()

while True:
    out = ''
    sys.stdout.write(ser.read(1024))
    sys.stdout.flush()
```

 SerialToStdout.py can be use instead of XBeeReceive with an XBee in transparent mode



XBeeSendCmd



- XBeeSendCmd
 - Main target is 802.15.4 XBee-based gateway
 - Send ASCII command with Xbee
 - Can be used to sent remote AT command to other Xbee module
 - Support DigiMesh firmware
 - Example
 - XBeeSendCmd -addr 0013a2004069165d "/@D0100#"

```
USAGE:
           ./XBeeSendCmd -p dev [-L][-DM][-at] -tinyos -tinyos amid id hex -mac|-net|-addr|-b message
USAGE:
           -p /dev/ttyUSB1
USAGE:
           -mac 0013a2004069165d HELLO
USAGE:
          -net 5678 HELLO
USAGE:
          -addr 64 or 16 bit addr HELLO
          -b HELLO
USAGE:
USAGE:
          -at to send remote AT command: -at -mac 0013a2004069165d ATMM
          -L insert Libelium API header
USAGE:
USAGE:
          -DM to specify DigiMesh firmware
          -tinyos to forge a TinyOS ActiveMessage compatible packet (0x3F0x05 are inserted)
USAGE:
          -tinyos amid 6F, to set the ActiveMessage identifier to 0x6F (0x05 is the default)
USAGE:
```



XBeeSendFile



- XBeeSendFile
 - Main target is 802.15.4 XBee-based gateway
 - Send binary files with Xbee with controlled timing
 - Can use any packet size between 1 and 100 bytes
 - Can insert framing bytes, can introduce packet losses



```
USAGE:
            ./XBeeSendFile -baud baudrate -p dev -timing tpkt us tserialbyte us tafterradio us -nw -fake -drop
rate -v val -fill -pktd -pktf -size s -stdout -mac|-net|addr|-b file
            -baud 125000, 38400 by default
USAGE:
USAGE:
           -framing, will use framing bytes 0xFF0x55+SN for binary packets (e.g. audio)
USAGE:
           -timing 50000 20 25000 by default
USAGE:
           -nw, do not wait for TX status response
USAGE:
           -fake, emulate sending. Will write in fakeSend.dat
           -drop 50, will introduce 50 of packet drop. Useful with -fake
USAGE:
           -v 77, use 0x77 to fill in missing bytes in lost packet
USAGE:
USAGE:
           -fill, will fill missing bytes
USAGE:
           -pktd, display generated XBee frames
USAGE:
           -pktf, generate a pkt list file
USAGE:
           -size 50, set packet size to 50 bytes
USAGE:
           -stdout, write to stdout for pipe mode
USAGE:
           -mac 0013a2004069165d
USAGE:
           -net 5678
USAGE:
           -addr 64 or 16 bit addr, set either 64-bit or 16-bit dest. address
USAGE:
            -b
```




WaspMote+XBee in raw mode

 Electret mic with amplifier

XBee in AP0 mode (transparent mode)

8-bit 4Khz sampling gives 32000bps

 8Khz sampling gives 64000bps, requires custom API








ONLY 1 HOP!






Details of pin connection





WaspMote test-bed: XBee gw APC



```
void loop() {
   val = analogRead(ANALOG2); // read analog value
   val8bit = ((val >> 2)); // convert into 8 bit

   // write on UART1, need an XBee module
   // with AP mode 0

   serialWrite(val8bit,1);
}
```



With XBee GW also in AP0 mode

```
4KHz sampling
> XBeeReceive -baud 38400 -ap0 -stdout dumb.dat | play --buffer 50 -t raw -r 4000 -u -1 -

8KHz sampling
> XBeeReceive -baud 125000 -ap0 -stdout dumb.dat | play --buffer 50 -t raw -r 8000 -u -1 -

Save raw data for off-line playing
> XBeeReceive -baud 38400 -ap0 -stdout dumb.dat > test.raw
> play -t raw -r 4000 -u -1 test.raw
```

Alternatively using SerialToStdout python script, at 38400 baud only

```
> python SerialToStdout | play --buffer 50 -t raw -r 4000 -u -1 -
```



XBee gateway in pkt mode (AP2)

- The receiving XBee module may need to be in packet mode (AP2) due to deployment constraints
- Adds overhead of XBee API frame decoding: 8KHz sampling may be not supported


```
4KHz sampling
> XBeeReceive -baud 38400 -stream dumb.dat | play --buffer 50 -t raw -r 4000 -u -1 -

Save raw data for off-line playing
> XBeeReceive -baud 38400 -stream dumb.dat > test.raw
> play -t raw -r 4000 -u -1 test.raw
```





Multi-hop audio constraints






Multi-hop audio solution



 Use dedicated audio board for sampling/storing/encoding at 8kbps




 Allows for multi-hop, encoded audio streaming scenarios



Details of pin connection







AdvanticSys+audio board




- The audio board captures 160 bytes (20ms) of raw audio and uses speex codec at 8kbps to produce 20 bytes to encoded audio data
- It sends the encoded audio data through an UART line to the host micro-controller
- The host micro-controller receives the encoded data and sends them wirelessly to the next hop
- The last hop is a base station that will forward the encoded audio into a speex audio decoder
- Output of the speex audio decoder is in raw format that can be feed into a player (play)





speex at 8kbps



the sounds of smart environments



AdvanticSys+audio board





post sendMsg();





With AdvanticSys base station (115200 baud)

> python SerialToStdout | speex sampledec wframing | play --buffer 100 -t raw -r 8000 -s -2 -

With XBee GW in AP0 mode



```
> XBeeReceive -baud 38400 -B -ap0 -stdout dumb.dat | speex_sampledec_nframing play --buffer 100 -t raw -r 8000 -s -2 -
```


With XBee GW in AP2 mode (pkt mode)

```
> XBeeReceive -baud 38400 -B -stream dumb.dat | speex_sampledec_nframing play --buffer 100 -t raw -r 8000 -s -2 -
```



Relay nodes





LIBELIUM WASPMOTE



ADVANTICSYS CM5000, CM3000

Fully configurable:

Destination node
Additional relay delay
Clock synchronization

R0/1 enable/disable relay mode D0013A2004086D828 set the 64-bit dest. mac addr D0080 set the 16-bit dest. mac addr



Multi-hop test-bed w/audio board





SPEEX AUDIO ENCODING 8KBPS

A1/2/3/4 aggregate audio frames


D0080 set the 16-bit dest. mac addr C0/1 power off/on the audio board

D0013A2004086D828 set the 64-bit dest. mac addr

 0×0020

RELAY

RELAY



 0×0030

R0/1 enable/disable relay mode

D0013A2004086D828 set the 64-bit dest. mac addr

D0080 set the 16-bit dest. mac addr



 0×0040

DECODE & PLAY RECEIVED AUDIO




Generic & controlled sender



Use a generic sender node to test with a larger variety of audio codec: store encoded audio file on SD card. Audio encoding is done on desktop computer

Do not need specific audio encoding hardware to test quality of streaming encoded audio data




Fully configurable:

Destination node
Clock synchronization
File to send
Size of packet chunk
Inter-packet delay
Binary/Stream mode



Multi-hop test-bed w/generic sender




RELAY

0x0030

T130 transmit with inter pkt time of 130ms
Z50 set the pkt size for binary mode
Ftest2400.bit set the file name to test2400.bit
D0013A2004086D828 set the 64-bit dest. mac addr
D0080 set the 16-bit dest. mac addr
B or S set to binary mode/set to stream mode

All commands must be prefixed by « /@ » and ended/separated by « # »

/@T130#, /@Ftest2400.bit#B#



0x0040



DECODE & PLAY RECEIVED AUDIO



codec2/speex with generic sende

- Use codec2/speex encoding software to produce encoded audio file
- Store encoded audio file (.bit/.spx) on SD card
- Configure the generic sender for sending the encoded audio file
 - Define packet size
 - Determine inter-packet send time
- Receive the encoded audio stream, decode the data and determine audio quality


Produce encoded audio file: codec2


- Initial file: test.raw in 16-bit, signed
- Use sox to get 16-bit, signed if your raw file is not in this format
- Encode at 2400bps with
 - c2enc 2400 test.raw test2400.bit
- Store test2400.bit on SD card



Codec2 encoding










Codec2 at 2400bps & 3200







Multi-hop tests with codec2







0x0020




RELAY

SAMPLE AUDIO: 13S PCM = 104000B CODEC2 AT 2400BPS GIVES 3900B

/@Ftest2400.dat#B#
/@Z40#
/@T90#

RELAY



0x0030

0x0040

STORE & PLAY

- > XBeeReceive -framing -B rcv-test2400.bit
- > c2dec 2400 rcv-test2400.bit | play -t raw -r 8000 -s -2 -

STREAMING

> XBeeReceive -framing -B -stdout rcv-test2400.bit | bfr -b1k -m2% - | c2dec 2400 - - | play -t raw -r 8000 -s -2 -

DECODE & PLAY
RECEIVED AUDIO

the sounds of smart environments

- Initial file: test.raw in 8-bit unsigned or 16-bit signed
- Encode at 8000bps with
 - speexenc --8bit --bitrate 8000 test.raw test8000.spx
- Produce a raw speex byte stream with modified version of speexdec
 - speexdec test8000.spx > t8000raw.spx
- Store t8000raw.spx on SD card





Multi-hop tests with speex







0x0020




RELAY

RELAY

SAMPLE AUDIO: 13S PCM = 104000B SPEEX AT 8000BPS GIVES 14368B

/@Ft8000raw.spx#B# /@Z25# /@T20# /@Ft8000raw.spx#S# /@Z21#



0x0030

0x0040

STORE & PLAY

- > XBeeReceive -framing -B t8000raw.spx
- > cat t8000raw.spx | speex_sampledec_nframing | play -t raw -r 8000 -s -2 -



STREAMING

> XBeeReceive —B -stdout -stream t8000krw.spx | bfr -b1k -m2% - | speex_sampledec_wframing | play -t raw -r 8000 -s -2 -

DECODE & PLAY RECEIVED AUDIO



Frame analysis




- Use wireshark as frame analysis tool
- AdvanticSys TelosB mote as promiscuous sniffer mote, connected to wireshark to display captured frames
- Frame reception time can be visualized for statistic collection
 - Transmission latencies
 - Frame jitter





wireshark frame capture








Sensitivity of codecs



LAB TESTS





Apply packet loss rate




- Use XBeeSendFile to control
 - Timing between packet sending



Packet loss probability


Codec2 2400bps, series of 6-byte encoded audio packets



> XBeeSendFile -fake -drop 25 -stdout test2400.bit > test2400-25loss.bit



> XBeeSendFile -fake -v 77 -fill -drop 25 -stdout test2400.bit > test2400-25loss-fill.bit



77 77 77 77 77